

Type 590X

I/P Transducer

Installation, Operation and Maintenance Instructions




FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6

© 2018 Wärme Indústria e Comércio S.A. Todos os direitos reservados.

Use this coding system to order:



Contents

Section	Description	Page
1.0	Installation & Approval	3
2.0	Operation	6
3.0	Maintenance	7
4.0	Troubleshooting	8
5.0	Warranty	8

DANGER, WARNING, CAUTION and NOTE statements

DANGER

Refers to conditions or hazards which could result serious personal injury or death.

WARNING

Refers to conditions or hazards which could result personal injury.

CAUTION

Refers to conditions or hazards which could result equipment or property damage.

NOTE

Provides useful hints or special instructions.

ALL DANGER, WARNING, AND CAUTION STATEMENTS MUST BE COMPLIANT WITH EN 60335-1.

SPECIFICATIONS

Functional Specifications

	M-Connection	F-Connection
Level	0-20 mm	
Outputs	2-10 mm ² max 0-20 mm ² max 0-20 mm ² max	0-20 x 0.8 mm ² 0-20 x 0.8 mm ² 0-20 x 0.8 mm ²
Air Consumption	1.00 m³/m² @ 20 mmHg max. 0.50 m³/m² @ 0.50 mmHg max. 0.10 m³/m² @ 0.10 mmHg max.	1.00%
Supply Pressure <small>ref. to the pressure measured upstream of the filter and the control valve</small>	0.10 mmHg (0.8 kPa) max.	0-10 mmHg (0.8 kPa) max. 0-20 mmHg (1.6 kPa) max. 0-20 mmHg (1.6 kPa) max.
Flow Capacity	Same as Air Consumption	1.0 m³/m² max.
Temperature Limits	-10°C to +60°C (-20°C to 150°C)	
Relative Humidity	10% average - 90% short time max. condensing	
Impedance	0.05 mmHg @ 10 l/min	
Loop Load	0.2 mmHg @ 10 l/min	

Performance Specifications

Linearity (Independent)	±0.5% of span	
Hysteresis	±0.1% of span	
Repeatability	±0.1% of span	
Responsibility	±0.2% of span, ±0.1% of span typical	
Mounting Orientation	±0.5% (0-100% range)	
Air Sample Sensitivity	±0.1% (0.1 mmHg change)	±0.1% (1.0 mmHg change)
Vibration Effect	±0.1% up to 10g and 20-80 Hz	
Temperature Effect	±0.1% (10°C change)	

Physical Specifications

Mounting	DINRAIL 35mm rail	
Port Size	1.5" NPT (IP-Connections)	
Media	Clear, dry, oil-free, instrument air filtered to 40 micron	
Electrical Connections	Terminal block	
Mounting	Type DIN rail or manifold	
Material	Body:	Stainless-steel or brass, (316SS)
	Exhaust:	Brass
	Trim:	Stainless steel brass, zinc-plated steel
	Mount:	Polycarbonate
Weight	0.75 lbs (0.34 kg)	

1. INSTALLATION AND APPROVALS

1.1 Installation Requirements

1.1.1 Environment: Suitable for installation in the following systems:

- Intrinsically safe operation in hazardous locations (Class I)
- See sections 1.5, 1.6 and 1.7 for Factory Mutual (FM), Canadian Standards (CSA) and ATEX approvals.

CAUTION

All wiring must be made to all local and national codes applicable to the area of installation.

1.1.2 Electrical Load: 4 (2 mA) current points.

1.1.3 Air supply: Clear, dry, oil-free instrument air filtered to 40 micron.

NOTE

Check all pipe lines to be connected and make good to installation. Features attributable to equipment air supply connections are not covered by the warranty.

CAUTION

This instrument vents to atmosphere. The use of supply gas other than air can create a hazardous environment.

WARNING

The recommended cover of the IEC enclosure is considered to constitute an electrically insulating barrier. The IEC cover must be secured as part of a locked structure. The IEC enclosure enclosure is made from metal and is grounded as part of a locked structure. The IEC enclosure enclosure contains hazardous and is considered to constitute a potential risk of ignition by impact or friction produced by taking into account during operation.


If the type of enclosure is treated as category 2 equipment, then it shall be installed in an enclosure which maintains an ingress protection rating of IP65 and meets the enclosure requirements of Division 1 or 2.

The user shall permanently mark the protection type chosen. Once the type of protection has been marked, it shall not be changed.

1.2 Mounting

- 1.2.1 The Type 8504 can be mounted to DIN rail using the optional kit that is (optional part number 445-788-026). This kit allows the transducer to mount to DIN 8040, 8045, 8046, 8047 rails (see figure 1).

Figure 1 - DIN Rail mounting kit 445-788-026



1.3 Pneumatic Connections

- 1.3.1 Clean all pipe lines to remove dirt and scale prior to installation.
- 1.3.2 Supply air must be filtered to ISO-class 4 and free of moisture and lubricants.
- 1.3.3 One 1/8" NPT port is provided for supply air connection.
- 1.3.4 One 1/8" NPT port is provided for pneumatic output connection.

1.4 Electrical Connections

- 1.4.1 The Type 9500 is a two wire device (does not require a separate power source). It requires a variable input current of 4-20 mA.
- 1.4.2 Electrical connection is made to the positive (+) and negative (-) terminals. For direct wiring operation connect the positive side of the input signal to the (+) terminal (see Figure 2).

NOTE The use of shielded cable is recommended.


Figure 2 – Terminal Block Connections



1.5 FM Approvals (FM) & Canadian Standards (CSA) Approvals

Flammable Liquid Units: FM & IMA
Inherently Safe
Class I, Div. 1 - Groups A, B, C, D
Install in:
Class I, Div. 1 - Groups A, B, C, D
Temp. Class 1B T&C

EMC Parameters
UL 1741 - 30 VDC
IEC 61000-4-4
UL 94 V-0
UL 100
IP = 6, 7, 8 max.



1.6 ATEX Approvals

Flammable Liquid Units: ATEX

Flammable Liquid Units:
ATEX
ATEX 100 (I, II, III, IV, V) - Groups A, B, C, D
ATEX 200 (I, II, III, IV, V) - Groups A, B, C, D
ATEX 200 (I, II, III, IV, V) - Groups A, B, C, D
ATEX 200 (I, II, III, IV, V) - Groups A, B, C, D
ATEX 200 (I, II, III, IV, V) - Groups A, B, C, D



Flammable Gas Units:

ATEX	II	III	IV	V
ATEX 100	ATEX 100	ATEX 100	ATEX 100	ATEX 100
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200
ATEX 200	ATEX 200	ATEX 200	ATEX 200	ATEX 200

4.2 INSTALLATION DRAWING
REV. 01/2018

1. O sistema deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente.

2. Deve ser observado o tipo de instalação recomendado para cada modelo de equipamento. O equipamento deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente. O equipamento deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente.

3. O equipamento deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente.

4. Deve ser observado o tipo de instalação recomendado para cada modelo de equipamento.

5. O equipamento deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente.

6. O equipamento deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente.

7. O equipamento deve ser instalado em um local adequado para o acesso ao equipamento e para a manutenção, com espaço livre suficiente.



CONEXÃO ALIMENTAÇÃO 220V
 220V
 220V
 220V
 220V
 220V

CONEXÃO ALIMENTAÇÃO 110V
 110V
 110V
 110V
 110V
 110V

LEGENDA

TIPO	1	2	3	4
1				
2				
3				
4				

4.8 CE Declaration of Conformity

Wärme Automação, S.A.
R. Columbus Drive
Londrina, PR 86051



Declare that the Type 8833 Transducer family to which this declaration applies:
Conforms to the emissions requirements of the standards EN61326-1:2009 and EN61326-2-2:2009
Class A, Restricted Emissions, 200MHz to 1GHz
Conforms to the immunity requirements of EN61326-1:2009, EN61326-2-2:2009 and EN61010-1:2010.

5. OPERATIONS

5.1 Calibration

5.1.1 All units are shipped from the factory calibrated, direct acting.

NOTE Factory calibration is responsible to shift due to handling during transit. Customer responsibility should exist for recalibration after transit.

5.1.2 Though the units are shipped fully calibrated it is suggested that the user check the calibration to ensure that settings and operation match the application requirements.

5.2 Direct Acting Calibration

5.2.1 In direct acting operation the unit is calibrated so that minimum input signal corresponds to minimum output pressure and increasing input signal results in increasing output pressure.

5.2.2 Apply the minimum input signal of the range being used (e.g. 1 mV for a 0-20 mA unit).

5.2.3 Observe the output pressure. If necessary, adjust the zero screw until reaching minimum output pressure setting. Note zero screw clockwise to increase and counter clockwise to decrease.

5.2.4 Apply the maximum input signal of the range being used (e.g. 20 mA for a 0-20 mA unit).

5.2.5 Observe the output pressure. If necessary, adjust the span screw until reaching maximum output pressure setting.

NOTE For an indirect acting module, zero span screws clockwise to increase pressure, counter clockwise to decrease pressure.

5.2.6 After setting the span it will be necessary to recheck the zero. Repeat steps 1-4 until both end points are at required values.

5.3 Reverse Acting Calibration

5.3.1 For reverse acting calibration, consult the factory.

3. MAINTENANCE AND REPAIRS

NOTE

Under normal circumstances, no maintenance should be required.

3.1 Instrument Air Filtration

- 3.1.1 Failures due to instrument supply air contamination are not covered by warranty.
- 3.1.2 Use of an alcohol water saturated instrument air-dryer causes erratic operation.
- 3.1.3 Poor quality instrument air can result in unit failures. It is recommended that a filter-regulator (such as ControlAir Type 500) be placed upstream of each unit where oil and/or water laden instrument air is suspected.

3.2 Factory Repairs

- 3.2.1 In the event of unit failure, the Type 500A can be returned to the factory through point-of-purchase for warranty repair if the warranty period has not expired.
- 3.2.2 All units returned for repair must be authorized prior to receipt at the factory. Contact a representative at the point of purchase, receive a Return Authorization Number.


3.3 Field Repairs

- 3.3.1 Service kits for electrical components in the Type 500A are available. Consult factory for kit numbers and availability.
- 3.3.2 Replacement components for the Type 500A are available. Consult factory for part numbers and availability.

3.4 Filter Replacement

- 3.4.1 Supply pressure can become obstructed should the felt filter element become clogged. To replace filter (FH-369-TT-C16), remove clogged plug and carefully remove filter using hex keys. Ensure no ball or O-ring remains in filter chamber. Feed new filter into chamber in orientation as shown in figure 5. Replace clogged plug, ensuring O-ring is properly seated.

Figure 5 – Replacing Filter



4. TROUBLESHOOTING

PROBLEM	LOOK FOR:	SOLUTION
No or low output	Zero adjustment Clogged filter Supply pressure too low	Reset zero (2.2.3) Replace filter (see figure 1) Increase supply pressure (see specs)
Unstable / low output	Electrical connection	Check connection/signal (3.3.2)
Erratic operation	Liquid contamination in air supply	Check air supply (1.1.1)
Works in reverse	Pressure goes down when signal is increased	Reverse input wires (1.4.1)
Output equals supply pressure	Improper pneumatic connections	Input that supply is connected to "IN" port and output is connected to "OUT" port (1.3.3, 1.3.4)

NOTE

If problems are not solved by troubleshooting procedures, contact a factory applications engineer at phone 800-8488 for further assistance.

5. WARRANTY & DISCLAIMER

ControlAir, Inc. products are warranted to be free from defects in materials and workmanship for a period of eighteen months from the date of sale, provided said products are used according to ControlAir, Inc. recommended usages. ControlAir, Inc.'s liability is limited to the repair, purchase price refund, or replacement in kind, at ControlAir, Inc.'s sole option, of any products proved defective. ControlAir, Inc. reserves the right to discontinue manufacture of any products or change products materials, designs or specifications without notice. Thus, ControlAir does not assume responsibility for the selection, use, or maintenance of any product. Responsibility for the proper selection, use, and maintenance of any ControlAir product remains solely with the purchaser and end-user.

WARNING

These products are intended for use in industrial compressed-air systems only. Do not use these products where pressures and temperatures can exceed those listed under specification.